

Digi-Star

GT400

1. Turn the GT400 indicator on.
2. Press and hold the "Field" button until "LB" begins to flash, then release. Then press the "ON/OFF" button to begin a self-test.
3. Wait for the calibration number to be displayed, as indicated by "CAL," and press the "ON/OFF" button to pause, if necessary.
4. Write down the calibration number displayed.

GT460

1. Enter 872 then press the "Select" button.
2. Write down the calibration number displayed.

Avery Weigh-Tronix

Model 640

1. Enter G/N mode, then press and hold the "HOLD/MENU" button for three beeps and release. "SET.PAS" should be displayed.
2. Enter the password 640, using the "RM" button to increment the number, the "M+" button to decrement the number, the "HOLD/MENU" button to advance the cursor, and the "PRINT/SELECT" button to accept it.
3. Press the "PRINT/SELECT" button to display "CONFIG".
4. Press the "HOLD/MENU" button to display "CUSTOM".
5. Press the "PRINT/SELECT" button.
6. Write down the calibration number displayed.